

## How to Hard boil an Egg

1. Fill a small pot ½ way with cold water and cover.
2. Turn stove on high until the water comes to a boil.
3. Use a large spoon to gently lower egg or eggs into the boiling water to avoid cracking and leave top off of pot.
4. Turn down heat slightly to medium high to keep a slight boil for 10 minutes. SET TIMER FOR 10 MINUTES.
5. TURN STOVE OFF.
6. Let cool for 20 minutes and put eggs into a Tupperware in fridge.